

# Power Crystal™

Model No. 217

## Slate-Style Turkey Call



- High Frequency Crystal Surface
- Super Hard Surface
- 100% Waterproof
- Protective Lid

You have chosen a top-of-the-line, high-pitched, friction call. The Power Crystal's™ super-hard surface easily peaks at 15,000 Hz, due to a combination of the crystal surface and the acoustics of the pot's internal sounding board. Congratulations on choosing a top-of-the-line high-frequency call! Plus we are now providing a lid to protect the calling surface.

Speak The Language®

*Will Primos*  
Will Primos

**IMPORTANT: Please read all instructions and warnings before using this product to ensure safe and proper use.**

### INSTRUCTIONS


**PREPARING THE CRYSTAL SURFACE:** The crystal surface of your call comes unfinished so that you can etch the surface according to your own personal taste. This crystal surface is super hard, which allows the call to quickly and easily reach pitches of 15,000 Hz.

We have provided two abrasive pads with your call - one coarse and one finer grit. Use the coarse grit to initially prepare the surface. You can etch the entire surface, or you can etch just a small section, depending on what you like. Sand your crystal in one direction. Use the finer grit to finish the surface. It will take up to five minutes to initially prepare the crystal surface. You are now ready to enjoy the high quality sounds of The Power Crystal™ that gobblers find so irresistible.

### EXERCISES

Your striker hand should rest firmly on the rim of your call. The striker should be held as you would hold a pencil, only about two inches up from the end (See Diagram). The sound you produce will depend on:

1. How tightly you hold the striker
2. How much pressure you apply to the crystal with the striker
3. The angle of your striker in relation to the crystal



Place your striker perpendicular to the crystal surface, then tilt your striker away from your body so that it is about 45° from the crystal. Experiment with different striker angles and pressure against the crystal surface to find what is best for you (See Diagram).

1. **Purr** - Slowly drag striker 3/8" to 1/2" across the crystal. Try dragging the striker in a straight line or "J" shape. Repeat this movement for each purr without removing the striker from the crystal surface.
2. **Yelp** - Quickly move striker across the crystal in a 1/2" to 1" oval shape. Repeat this movement for each yelp without removing the striker from the crystal surface.
3. **Cluck** - With light pressure, quickly move striker 1/8" to 1/4" across the crystal. Repeat this movement for each cluck without removing the striker from the crystal surface.
4. **Cutting** - With firm pressure, quickly jerk the striker 1/8" to 1/4" across the crystal surface and back, repeating the movement for each cut without removing the striker from the crystal surface.

**FREE CATALOG IN USA 800-622-8076**

**SPECIAL NOTE - CLEANING YOUR STRIKER:** You must keep the tip of your striker clean and free of any build up. To clean the striker, use the abrasive pads and lightly sand the tip of your striker.

**RESURFACING YOUR CALL:** Keeping your Power Crystal™ roughed up with the enclosed abrasive pads will produce the best results. To resurface and clean your Power Crystal™, apply the abrasive pads across the crystal surface in one direction or a in circular motion.

**WARNING:** Primos® game calls are so accurate that you might attract other hunters, as well as game. The user of this product assumes all risk of injury in association with the use of this product.



All Primos® game calls come with a Limited Lifetime Service Guarantee. For warranty or service information, email [service@primos.com](mailto:service@primos.com) or call customer service at (601)879-9323.

# PRIMOS

[primos.com](http://primos.com)

